Barno. 1 Installation Instructions

ARTICLE. 19901

Before installation:

- 1. Check the local laws & regulations and the region your vehicle may travel to for Driving light before installation, ensure they are compliance.
- 2. Read all installation instructions.
- 3. Make sure the dimension and weight of the lamps and device are matched to your vehicle.
- 4. Slight moisture inside may be existed, it will be removed out from the vent after 2-4 time working.
- 5. Working Voltage: 10-32V DC.

Mounting:

- 1. Determine the installation location, use a 11 mm drill 1 or 3 holes, lock nut tightening.
- 2. Use the stay bar if it is needed for stabilization.

Wiring connections & Functions:

1. Wiring connections

Black: Ground,-

Red: Driving Light,+

White: White position light, +

2. Wiring Harness, 40A relay, 30A fuse.



